

Quick Start Guide

Cascadia Networked Instructional Audio System

POWER **STATUS**


When the C25 is powered and ready to use, the Power light will glow. The C25 will enter a low-power mode after one hour of inactivity and the Power light will turn off. Removing a paired microphone from the cradle charger will wake up the C25.





CLEARMIKE OPERATION (default screen shown)

NOTE: Alert functions only available if integration is connected/enabled during setup.



PROGRAMMABLE ALERT FUNCTIONS

- BLANK: No function

- CHECKIN: Check-in during emergencies

PROGRAMMABLE BUTTON 1 (Press and hold for 2 seconds)

PROGRAMMABLE BUTTON 2 (Press and hold for 2 seconds)

EMERGENCY ALERT

HOW TO PLACE A CALL **FROM YOUR CLEARMIKE**

NOTE: Function only available if feature was enabled during intital setup.

- 1. Plug earbud into the 3.5mm jack on the microphone.
- 2. Insert earbud into ear.
- 3. Push and hold the button on the microphone with a Call label for 2 seconds.
- 4. Display will change to "Calling".
- When call connects display will 5. change to "Call in progress".
- 6. Press "Cancel" to hang up call.



PAIRING MICROPHONES TO THE C25




1

Your system is shipped with microphones and base units pre-paired for quick and easy use. If you ever need to pair new components, follow the pairing process below.

PLEASE NOTE: Microphones should be out of the charger while pairing.

POINT CLEARMIKE AT C25

From a powered off state, point the IR transmitter lens toward the C25.



2 PRESS AND HOLD POWER BUTTON

Press and hold the Power/Mute button for 5 seconds until the Talk/Mute light starts flashing blue and white. The Power Status light on the C25 will also start flashing blue and white.

3 CONFIRM STATUS

When complete, the Power Status light on the C25 will turn blue, the Talk/Mute light on the microphone will be white, and the display on the microphone will say "Pair Success".



INSTALLATION GUIDE

For installation instructions, go to www.lightspeed-tek.com/C25-installation-guide (or scan the QR code).



USER MANUAL

For complete operating instructions, go to www.lightspeed-tek.com/C25-usermanual (or scan the QR code).

